



Rez AG/SA/LTD.  
 Furkastrasse 25, 3904 Naters  
 Schweiz/Suisse/Switzerland  
 Telefon ++41 27 922 40 92  
 Telefax ++41 27 922 40 91



Wärmetechnische Apparate

## Airstream 2000 / ST

230 V ~ (S)

**Schema di montaggio e allacciamento per l'asciugamani elettrico Airstream 2000**  
 (Classe de protezione II)



(Questo apparecchio non è destinato ad uso domestico, bensì per impiego in impianti e stabilimenti pubblici; allacciamento per cavi installati fissi).

### Montaggio:

1. Togliere la scatola dell'apparecchio. A questo scopo svitare la vite Parker che si trova sotto, al centro dell'apparecchio. Spingere indietro i due nasetti A/A che si trovano sotto, su entrambi i lati e togliere la scatola sfilandola verso l'alto.
2. Utilizzando questa mascherina, trapanare 4 fori di 10 mm e mettere i tasselli.
3. Montare l'apparecchio sulla parete, utilizzando le viti ed i tasselli forniti.

Allacciamento elettrico: L = fase 230 V/2000 W/50 Hz ~      N = neutro

### Messa in servizio:

1. Quando si rimette la scatola, controllare che i nasetti C/C sopra ed i nasetti A/A sotto si incastrino bene nelle rispettive sedi. Fissare di nuovo la scatola con la vite.
2. Mettere le mani davanti all'apertura dell'aria calda. L'asciugatore si mette automaticamente in funzione e c. 3 secondi dopo aver tolto le mani dalla zona dell'aria calda dovrebbe spegnersi. Dopo l'installazione, si consiglia di ripetere l'operazione 3-5 volte.

### Danni di trasporto:

Controllare il contenuto della spedizione. Notificare immediatamente dopo il ricevimento della merce all'ufficio postale o ferroviario competente gli eventuali danni di trasporto.

### Garanzia: (1 anno dalla data della fattura)

Il numero di fabbricazione dell'apparecchio sostituisce il certificato di garanzia. Le riparazioni rese necessarie in seguito ad errori di allacciamento, trattamento violento o impiego errato non sono coperte da garanzia.

**Installation and electrical connection diagram for the Airstream 2000 hand drier**  
 (safety class II)



(This unit is not intended for domestic use but for public installation and premises; for connection to permanently installed electrical wiring).

### Installation:

1. Remove the casing. This is carried out by removing the Parker screw at the bottom centre of the unit. Push back the two lugs A/A situated at the bottom, at the side of the unit and remove the casing by lifting up.
2. Use this hole plan to drill 4 holes 10 mm ficing and insert wall plugs.
3. Fit unit to wall using the plugs and screws supplied.

Electrical connection: L = phase 230 V/2000 W/50 Hz ~      N = neutral

### Placing in operation:

1. When refitting the casing, ensure that the lugs C/C at the top and A/A at the bottom are engaged. Fix casing in place with the screw.
2. Hold the hands in front of the hot air outlet. The drier starts automatically and should switch off approximately 3 seconds after removing the hands from the hot air zone. It is recommended that this procedure is repeated 3-5 times after installation.

### Transport damage:

Check the contents of the package. Immediately notify any transport damage on receipt of the unit to the responsible post or rail authority.

### Guarantee: (1 year from date of invoice)

The production serial number of the unit replaces the guarantee certificate. Repairs due to faulty connection, use of force or maloperation are not covered by the guarantee.